

WamBam

Fun Name. Serious Fence.

WINDSOR 5 FT VINYL PRIVACY FENCE (5'H X 6'W)


ASSEMBLY INSTRUCTIONS BL19107

60 MIN

Approximate assembly time

Want to see a video on how to
assemble this product?

Scan the QR code



GENERAL INFORMATION

MISSING OR DAMAGED PARTS?



➤ **Visit Our Website**
so we can help you right away!
parts.nychbrands.com

* You can also reach us via phone or email.

Hours of Operation - **Weekdays 9am-5pm EST**

To better help you, **please have the following**

- Your product number (**BL19107**)
- Your affected part letters
- Your original product box

NEED ASSEMBLY HELP?

If you are having problems with assembly or installation of this product,
please contact at:

📞 **704-892-5222 / 877-234-6196** ✉ **hmmm@wambamfence.com**

NEED TO RETURN?

If for some reason you need to return this product, please allow us to help resolve your issues first. If you still decide to return the product, **you will need to initiate the return from the company you originally purchased from.**

HAVE YOU CONTACTED YOUR LOCAL UTILITIES?

You must call your local utilities before you start installing your fence to avoid puncturing any unseen underground utilities, especially electrical or gas lines. Fortunately, this is made easy for you.



**Know what's below.
Call before you dig.**

- < Simply call **811** in the US or visit www.call811.com.
- < In Canada, visit www.tcenergy.com/vendors for a list of phone numbers by province.


IMPORTANT! UNSTABLE GROUND OR ROCK?




If you encounter rock or unstable ground, you can concrete the pipe into place either during installation or afterwards.

TIPS:

1. It is extremely difficult to move pipe anchors once they are driven into the ground, so carefully planning and measuring your fence is essential.
2. "It is recommended to install one complete panel first. After you are familiar with the process, you can proceed driving in all of your pipe anchors
3. If you wish to trim panels to a shorter length, use a fine-toothed metal or wood saw blade.
4. Optionally, for easier spacing of pipe anchors, you can use a piece of 1x4 wood lumber cut 69 $\frac{7}{8}$ " for step 2.3 on page 8.




5. If your yard is steeply pitched or is very uneven, you may need to stair-step your panels as illustrated below. Post heights can be trimmed down as necessary.




Warning: If your yard has a severe slope or elevation change greater than approximately 5" to 6" over one panel of fence, you will not be able to install this fence. Your post will not be long enough to accommodate this slope.

DETAILED PRODUCT DIMENSIONS AND SPECIFICATIONS




INSTALL ONE COMPLETE PANEL OF FENCE FIRST. Then proceed to install only one or two pipe anchors at a time, until you fully understand the fundamentals. This will help you to avoid repetitive mistakes.

STEP 1: LAY OUT MATERIALS





TIPS: SCREW USAGE

► **NOTE:** Use 1" Self-Drilling Stainless Steel Screws (I) for fastening your brackets into your posts and your 3/4" Self-Drilling Stainless Steel Screws (J) into your rails.






BEFORE YOU BEGIN. If you are using a post pounder remove your top donut and slide it up over the pipe. Your post pounder cannot be longer than 24".




ATTENTION: To remove the top donut, pull the donut tabs out and lift up.




INSTALL PIPE ANCHORS AND POSTS

STEP 1




TOOL OPTIONS FOR DRIVING THE PIPE ANCHOR INTO THE GROUND:




Purchase a post pounder at any hardware store, or go to www.wambamfence.com/ Post pounders cost \$30 to \$35.

STEP 2 ▶

Note: The distance between the inner plastic gears (not donuts) to the pipe should be $69\frac{7}{8}"$ (or center to center of pipe at 72").




▶ Identify the location of your second pipe anchor and drive it into the ground.




STEP 3 ▶


- ▶ If you removed the upper donut, slide it back down over the inner gear.




- ▶ Adjust the bottom and top donuts to compensate for a crooked pipe anchor.




Reminder: Pull the donut tabs out and lift up to remove and adjust the donut position.



TIPS:



► Use a shovel or claw hammer to loosen 2" to 4" of dirt around the base of the pipe anchor.




► Soak the ground with water.

► This will allow the post to easily insert itself into the ground.

STEP 4

► Slide the Posts (B) down over the donuts.




Recommended: On flat ground, bury posts approximately 3" in the ground and compact dirt around posts for increased stability.

INSTALL BRACKETS AND BOTTOM RAILS


STEP 5 ►

- Install (1) Bracket **(F)** on the post approximately 2" off the ground using (4) 1" Self-Drilling Stainless Steel Screws **(I)**.




STEP 6 ▶

- ▶ Place the second bracket over the opposite end of the Rail (D) and slide the rail down into the bracket on the opposing side.




- ▶ Use a level on the top of the bottom rail to determine the height of the opposing bracket, and mark for installation.




STEP 7 ▶

- ▶ Temporarily remove the bottom rail and install the lower brackets using (4) total 1" screws.



STEP 9 ▶


- ▶ Insert the bottom rail into the lower brackets.



Note: It is recommended to insert one side of the rail at a time to reduce conflict with screws inside of the bottom bracket.

STEP 10 ▶


- ▶ Secure the rail with (4) total $\frac{3}{4}$ " Self-Drilling Screws (J).



STEP 11 ▶


Step 1: Measure and mark where you want to place your middle bracket (C).

Step 2: Place your brackets and secure with (2) total 1" screws per bracket on each side.



STEP 12 ▶


- ▶ Insert the middle rail into the brackets and secure the rail with (4) total $\frac{3}{4}$ " screws.



STEP 13 ▶

Step 1: Measure and mark your top bracket's location at 53" from the top of the bottom rail to the bottom of the top bracket.


Step 2: Secure with (4) 1" screws through the pre-drilled holes on each bracket.



INSTALL PICKETS


STEP 14 ►

- Place in all of your pickets (H) ensuring they are all pushed down to the back of the rail and flush.




INSTALL RAIL AND POST CAPS

STEP 15 ▶




Note: Insert one side of the top rail into the bracket and align the pickets as you lower your top rail into the second bracket.



▶ Secure top rail with (4) $\frac{3}{4}$ " screws through the pre-drilled holes in the rail brackets.

STEP 16 ▶



▶ Trim down the tops of the posts if necessary, and install the Post Caps (A).

WamBam

Fun Name. Serious Fence.



6935 Reames Rd. Ste. K.
Charlotte, NC 28216



hmmm@wambamfence.com

704-892-5222
877-778-5733



WWW.WAMBAMFENCE.COM