

Urban Escape Vinyl Gate Kit w/Hardware

(6' High x 4' Wide - Adjustable Width)



ZIPPITY

Easy Does It!



This gate is designed to be integrated with our Urban Escape Vinyl Fence w/Post - 6' High.
(This gate can be easily trimmed down in width to accommodate shorter applications).

V-1.0

Please visit www.zippity-outdoor.com or call us at **1-877-234-6196** for answers to your other questions.
We are eager to help you succeed in your project. Thanks for choosing Zippity, and all the best with your project.

Urban Escape Vinyl Gate Kit w/Hardware

(6' High x 4' Wide - Adjustable Width)



ZIPPITY

Easy Does It!

1 - Read Over Fence Instructions First

Your gate and fence will work better together as an integrated solution if you first take the time to read and understand your fence instructions.




2 - Pre-Assemble the Gate (Dry Run)

Please do not screw your gate frame together until you have first temporarily assembled the gate. In other words, do a dry run first.

This will ensure three things:

- a) *That you have everything necessary to complete the gate.*
- b) *That you will have assembled the gate in the correct order.*
- c) *All the pieces fit and function properly.*

It's easier to trouble shoot when things are not screwed together. After you assemble your gate correctly, please disassemble as necessary and use screws to permanently assemble the gate.



3 - Ideally, Install Your Gate Posts Before Your Fence Posts



Your fence panels will be more forgiving for a custom fit than your gate. Ideally, position and install your gate posts before you do anything else, or very early on in the process of setting up your fence run.

4 - Ideally, Do Not Hang Your Gate System Off a Single Non-Supported Post

Your gate will perform better and last longer if your hinge post is connected to a panel of fence which is connected to another post. The weight strain will be transferred unto two posts versus just one. Installing fence panels on both sides of your gate is the ideal in all situations. If this is not possible because of space restrictions, please contact us for alternative solutions to overcome.




***Install Your Gate Posts
Before Installing Your
Fence Posts.***



Do Not Hang Gate on Lone Soldier Post.

Urban Escape Vinyl Gate Kit w/Hardware



(6' High x 4' Wide - Adjustable Width)




ZIPPITY
Easy Does It!

Product Overview

Gate Assembly




Gate Installation



Box Contents

Each Gate Box Includes:




Sold Separately:

- Fence Post (1-Pack)

This gate can be easily trimmed down in width to accommodate shorter applications. Use a circular saw with fine tooth blade.

Urban Escape Vinyl Gate Kit w/Hardware


(6' High x 4' Wide - Adjustable Width)




ZIPPITY

Easy Does It!


STEP 1 Assemble the Gate Posts and Boards




A - Identify the LEFT and RIGHT gate posts as illustrated. Orientate the pre-drilled holes as illustrated. The pre-drilled that is 3 inches from the end of the post is the top of the gate.




B - Slide the first board down into place (tongue facing up) until the bottom of the board is 1 inch from the bottom of post.



C - Fasten four, 2.5 inch screws through the pre-drilled holes as illustrated.




D - One by one, slide the remaining 5 boards down the groove of the posts.




E - Fasten 12 more screws through the pre-drilled holes as shown.

CORRECT




Secure screws straight and in the center.

WRONG




WRONG



Urban Escape Vinyl Gate Kit w/Hardware


(6' High x 4' Wide - Adjustable Width)




ZIPPITY

Easy Does It!


STEP 2 Assemble Gate Brace & Attach Post Caps




A - Measure diagonal distances and insure they are the same. This will ensure the gate is square. Diagonal measurements should be 85 7/8 inches.




B - Overlap the braces as illustrated.



C - Secure the braces into place using 9, 1.5 inch screws as illustrated.



D - Attach post caps as shown.



Urban Escape Vinyl Gate Kit w/Hardware

(6' High x 4' Wide - Adjustable Width)




ZIPPITY

Easy Does It!

STEP 3 Fasten Gate Latch & Gate Hinges Onto Gate

A



A - Fasten gate latch and hinges onto the gate with screws provided with each. Long screws for hinges. Short screws for latch.

Urban Escape Vinyl Gate Kit w/Hardware



(6' High x 4' Wide - Adjustable Width)



ZIPPITY

Easy Does It!


STEP 4 Position, Adjust & Align Gate/Secure Hinges to Posts




A - Use temp spacers or blocks to rest the gate on during alignment and installation.

B - Fasten hinges to post with screws.

STEP 5 Level Gate & Adjust Hinges




A - Fasten gate hinges accordingly.



B - Check for level, fit and function to latching post.



Urban Escape Vinyl Gate Kit w/Hardware

(6' High x 4' Wide - Adjustable Width)



ZIPPITY


Easy Does It!



C - Hinges can be adjusted moderately to bring gate into level alignment with post.

D - Latch is designed for left and right hand applications. Temporarily remove the spring, bolt and reverse paddle portion as necessary.

STEP 6 Align & Install Gate Latch



A - Align and fasten the gate latch catch to fit and function with the gate finger.

Congratulations!

Go grab a beverage of your choice, admire your handy work, and show us what you got by entering our annual photo/video contests!